

0514024

SUBJECT: Shouldered Stud Installation

PART/VEHICLE: G63929 (92- 07 Ford E-Series)

PROBLEM DESCRIPTION:

Installer unable to install the upper hardware on stud ended shocks designed with a “shoulder”. A shouldered stud is defined as a stud that has a non threaded zone that is larger in diameter than the threaded zone.

NOTE: *The mounting kit includes two retainers with different size holes*

Installing the retainer with the small hole first does not allow enough room to install the upper cushion, retainer and nut.



SOLUTION:

Installing the retainer with the large center hole first allows plenty of threaded area to install the shock.

